

---

# Table of Contents

## F01 Comfort Access

Subject	Page
<b>Introduction</b> .....	<b>5</b>
Keyless Vehicle Access .....	5
System Overview .....	6
Input/Output - Comfort Access .....	6
System Circuit Diagram - Comfort Access .....	8
<b>Functions</b> .....	<b>10</b>
Function Overview .....	10
Remote Control Function for Comfort Access .....	10
Passive Entry .....	11
Passive Entry at the Trunk .....	12
Passive Go .....	14
Issuing Start Enable .....	14
Passive Exit .....	15
Locking Procedure .....	15
Special Comfort Access Functions .....	16
Second ID Transmitter Remains in the Vehicle Interior .....	16
Identification Transmitter in Luggage Compartment .....	16
Starting the Engine without an ID Transmitter .....	16
Unintentional Wake-up Function .....	17
Locking with Engine Running .....	17
Emergency Start Coil .....	17
<b>System Components</b> .....	<b>18</b>
Control Unit .....	18
Control Elements .....	19
ID Transmitter .....	19
Voltage Monitoring .....	19
Data for Conditioned Based Service .....	20
Antennas for Comfort Access .....	20
Antenna Installation Locations .....	20
Exterior antennas .....	20
Interior antennas .....	20
Luggage compartment antenna .....	21
Outside Door Handle Electronics Module .....	22
Sensors .....	22

---

<b>Subject</b>	<b>Page</b>
Capacitive sensor 1 .....	.22
Capacitive sensor 2/piezo sensor .....	.22
Outside door handle Hall sensor .....	.23
Door Locks .....	.23

**BLANK  
PAGE**

---

# Comfort Access

**Model: F01/F02**

**Production: From Start of Production**

# OBJECTIVES

After completion of this module you will be able to:

- Understand the functions of Comfort Access on the F01/F02
- Understand the “Passive Go” functions on the F01/F02

# Introduction

## Keyless Vehicle Access

Using Comfort Access, the customer can unlock and open the vehicle without active use of the ID transmitter. Access to the vehicle can be gained from any point. It is important that the ID transmitter be located in the vehicle's immediate vicinity (approximately 5 feet). It is sufficient to have the ID transmitter somewhere on your person.

Comfort Access was first introduced on the E65 (03/2002). The system was then gradually introduced on different BMW models. There were the 1 Series, 3 Series, 5 Series, 6 Series, X5 and X6.

The F01/F02 will have Comfort Access from the start of series production in 09/2008. Comfort Access can be ordered as an option.

The benefits of Comfort Access are:

- High level of convenience when unlocking and locking the vehicle
- Convenient and fast access to the vehicle
- Simple engine start/stop procedure
- Maximum comfort for the driver
- No more annoying hunting for keys.

The Comfort Access in the F01/F02 is based on predecessor systems and is adapted to the F01/F02. However, the entire function is now located in the Car Access System 4. For this reason, there is no separate control unit for Comfort Access in the F01/F02, in contrast to previous systems.

The vehicle is unlocked when you place your hand into the handle recess on the outside of the door and opened when you pull the door handle.

You can lock the vehicle again by subsequently pressing on the sensitive surface of the outside door handle.

For vehicles fitted with Soft Close Automatic, the Soft Close Automatic drive fully closes the vehicle door. You can then lock the vehicle again by subsequently pressing on the sensitive surface of the outside door handle.


The ID transmitter must be located in the vehicle interior in order for the engine to be started. The engine can now be started by pressing the START-STOP button and the vehicle is ready to be driven.

**Note: In vehicles with automatic transmission, the brake pedal must be depressed in order for the engine to be started.**

**In vehicles with manual transmission, the clutch pedal must be depressed in order for the engine to be started.**

# System Overview

## Input/Output - Comfort Access




Index	Explanation	Index	Explanation
1	CAS 4 Car Access System 4	8	START-STOP button
2	Footwell module (FRM)	9	Antenna for Comfort Access
3	Junction box electronics (JB)	10	Outside door handle electronics module
4	Emergency start coil (transponder coil)	11	Lock with door contact
5	Central locking button	12	Driver's door lock cylinder
6	ID transmitter	CA	Comfort Access (function)
7	Diversity module	K-CAN2	Body CAN2

---

NOTES

PAGE

# System Circuit Diagram - Comfort Access





<b>Index</b>	<b>Explanation</b>	<b>Index</b>	<b>Explanation</b>
1	Footwell module (FRM)	14	Luggage compartment lighting
2	Junction box electronics (JB)	15	Interior antenna for Comfort Access, parcel shelf
3	Front distribution box	16	Luggage-compartment antenna, driver's side
4	Lock door contact, front-passenger side, front	17	Rear driver's side outside door handle electronics
5	Outside door handle electronics, front-passenger side, front	18	Lock door contact, driver's side, rear
6	Antenna for Comfort Access, door sill, front-passenger side	19	Antenna for Comfort Access, door sill, driver's side
7	Lock door contact, front-passenger side, rear	20	Outside door handle electronics, driver's side, front
8	Outside door handle electronics, front-passenger side, rear	21	Lock door contact, driver's side, front and locking cylinder in driver's door
9	Luggage-compartment distribution box	22	Car Access System 4 (CAS 4) with Comfort Access (CA) function
10	Luggage-compartment antenna, front-passenger side	23	Antenna for Comfort Access, interior, front
11	Central locking button	24	Antenna for Comfort Access, interior, rear
12	Antenna for Comfort Access, bumper	K-CAN2	Body CAN2
13	Trunk lock		

# Functions

## Function Overview

Comfort Access is divided into the following functions:

- Passive Entry
- Passive Go
- Passive Exit.

ID transmitters are required for Comfort Access to function.

An ID transmitter comprises, among other things:

- A battery
- Remote control function
- Transponder coil for emergency start function
- Mechanical key
- Receiver unit.

### Remote Control Function for Comfort Access

When the unlocking or locking button on the ID transmitter is pressed, it emits an encrypted remote control signal. The antenna in the rear window forwards the remote control signal to the diversity module. The diversity-module remote control receiver demodulates, processes and then sends the signal to the Car Access System on the LIN bus.

If the vehicle is in sleep mode, the remote control receiver wakes the Car Access System to reduced consumption mode via the LIN bus. The Car Access System thus receives the request that was sent using the ID transmitter. The ID transmitter is checked by the remote control receiver at this stage. If the result of the check is positive, the remote control receiver forwards the request via the LIN bus. If the request is authenticated, the Car Access System wakes the vehicle and initiates the unlocking or locking of the vehicle. To do so, the Car Access System issues the release signal for the junction box electronics to actuate the central-locking drive.


The ID transmitter can also be used to open the trunk separately. For this, only the button with the open trunk symbol need be pressed.

The Car Access System is responsible for communication via the LIN bus. The diversity module therefore only forwards the LIN bus signal if prompted to do so by the Car Access System 4. This applies to a vehicle that is not in sleep mode.

## Passive Entry

The graphic below shows the functional principle of “Passive Entry”.

### Signal path for Comfort Access in the F01/F02 Passive Entry System



Index	Explanation	Index	Explanation
1	Outside door handle electronics module (TAGE)	8	Car Access System 4 (CAS 4)
2	TAGE request to the CAS	LIN-Bus	Local Interconnect Network bus
3	Prompt about Comfort Access antenna	$f_1$	Low frequency in the kHz range
4	Comfort Access antenna	$f_2$	High frequency in the MHz range
5	ID transmitter	K-CAN2	Body CAN2
6	Rear window antenna	CA/FBD	Comfort Access/remote control services
7	Remote control receiver in the diversity module		

---

Passive Entry enables access to the vehicle without the ID transmitter being actively operated.

For example, if the outside door handle is pulled, this triggers a pulse in the sensor. The outside door handle electronics analyze the sensor and inform the Car Access System that vehicle access is requested.

The Car Access System prompts the ID transmitter to identify report to the vehicle. For this, a low-frequency signal is emitted by Comfort Access via the antennas. Transmission is via the 125 kHz antennas.

The 125-kHz signal serves only to wake the ID transmitter. The ID transmitter responds with its transmission frequency. Subsequent communication is now bi-directional, i.e. in two directions. The Car Access System sends or receives all further information via the LIN bus.

The remote control receiver is equipped with both a receiver unit and a transmitter unit. It establishes the connection with the ID transmitter via the rear-window antenna. For that reason, only the high frequency range is now used.

Bi-directional communication has the advantage that data can be requested from or sent to the ID transmitter. The Car Access System has sole responsibility for this communication.

If the ID transmitter is able to be authenticated, the Car Access System initiate the request, e.g. unlocking the vehicle. The junction box electronics execute the unlocking.

The transmission frequency of the ID transmitter varies for the US is 315MHz.

**Note: When it is not required, the ID transmitter is in sleep mode. This reduces its energy consumption. For sleep mode to be ended, the ID transmitter requires a wake-up signal. The wake-up signal can be sent by the Car Access System via the Comfort Access antennas. Pressing one of the buttons on the ID transmitter also wakes it.**

### **Passive Entry at the Trunk**

An authentication check also takes place before the trunk is opened.

If the outside trunk button in the trunk handle strip is operated, it changes its status. The junction box electronics analyze the status and send it via the K-CAN2.

The Car Access System 4 therefore knows that the outside trunk button has been operated.


The Car Access System initiates the emission of the 125 kHz signal, so that the ID transmitter can report to the vehicle.

At the same time, the Car Access System initiates communication to the ID transmitter.

The Car Access System sends the requests for this via the LIN bus to the remote control receiver. The latter sends the requests from the Car Access System via the rear-window antenna.

If the ID transmitter is recognized as belonging to the vehicle, the Car Access System prompts the junction box electronics to unlock the trunk.

### Principle of Comfort Access at the trunk



Index	Explanation	Index	Explanation
1	Outside trunk button in the handle strip of the luggage compartment lid	8	Remote control receiver in the diversity module
2	Junction box electronics (JB)	LIN-Bus	Local Interconnect Network bus
3	Car Access System 4 (CAS 4)	K-CAN2	Body CAN2
4	CAS request to the CA antenna	f <sub>1</sub>	Low frequency in the kHz range
5	Bumper antenna for Comfort Access	f <sub>2</sub>	High frequency in the MHz range
6	ID transmitter	CA/FBD	Comfort Access/remote control services
7	Rear window antenna		

---

## Passive Go

The “Passive Go” function makes it possible to start the vehicle when the ID transmitter is in the passenger compartment.

### Issuing Start Enable

Authorization to start the engine is only given when there is an ID transmitter in the vehicle. Once the last door is closed, the Car Access System begins its search for a valid ID transmitter.

The Car Access System 4 requests a signal to be sent out to identify a valid ID transmitter. The interior antennas are used for this.

The ID transmitter responds using a high-frequency range (315 MHz). If the ID transmitter is authenticated, the Car Access System 4 grants permission for the engine to be started.

**Note: The electronic immobilizer gives its own approval for the engine to be started.**

The search for an ID transmitter in the passenger compartment can also be triggered by pressing the START-STOP button. This will take place if the START-STOP button is pressed before the last door is closed, for instance.

Or if the vehicle is stationary too long and therefore loses communication with the ID transmitter. Pressing the START-STOP button triggers the search for the ID transmitter in the vehicle interior.

---

## Passive Exit

The Passive Exit function makes it possible to lock the vehicle without actively using the ID transmitter.

### Locking Procedure

After the vehicle door has been closed, the locking procedure is started by pressing the sensitive area on the outside door handle. The outside door handle electronics module sends the request to unlock the vehicle to the Car Access System 4.

The Car Access System 4 checks whether a valid ID transmitter is in the vicinity of the outside door handle using the outside antennas.

The ID transmitter is instructed to send an authentication signal.

In turn, the identification sensor sends encrypted data via the high-frequency link to the remote control receiver.

The remote control receiver processes the data and sends it via the LIN bus to the Car Access System. The Car Access System causes the communication with the ID transmitter to be established.

If the ID transmitter is recognized as belonging to the vehicle, the Car Access System 4 issues authorization for the vehicle to be unlocked.

The junction box electronics activate the central-locking drives.

---

## Special Comfort Access Functions

The Comfort Access additionally features the special functions described in the following that are determined by the actions of the vehicle user.

### **Second ID Transmitter Remains in the Vehicle Interior**

By checking via the interior antennas, the Car Access System 4 recognizes whether there is a valid ID transmitter in the vehicle interior. If the Car Access System 4 detects a valid ID transmitter in the vehicle interior and the vehicle is locked by means of another valid ID transmitter (located outside), the ID transmitter located in the vehicle interior is set to "blocked".

This ID transmitter will not be recognized as belonging to the vehicle for Comfort Access until the vehicle is unlocked again.

**Note: The "blocked" status only applies to the functions of Comfort Access.**

**The remote control functions are still available.**

### **Identification Transmitter in Luggage Compartment**

If an ID transmitter is located in the luggage compartment when the vehicle is locked and the trunk open and the trunk is then closed, the trunk will immediately be automatically opened again. Audible and visual signals draw the customer's attention to the fact that the ID transmitter is located in the luggage compartment.

The Car Access System 4 starts the request via the luggage-compartment antennas.

If a valid ID transmitter is detected in the luggage compartment, the Car Access System 4 will not issue authorization for the trunk to be locked.

The trunk cannot be closed before the ID transmitter has been removed and is located outside the luggage compartment.

**Note: This behavior only occurs if the Comfort Access does not find a valid ID transmitter in the vicinity of the vehicle when it searches the outside of the vehicle.**

### **Starting the Engine without an ID Transmitter**

This function makes it possible to start the vehicle within 10 seconds after "engine OFF" without detecting the ID transmitter. This function is intended for cases where, for example, the ID transmitter is not detected due to high-frequency interference.



---

## Unintentional Wake-up Function

The vehicle cannot be woken simply by someone gripping the outside door handle. A valid ID transmitter must be detected in the vicinity of the vehicle.

## Locking with Engine Running

The vehicle can also be unlocked with the engine running if the engine was started with Passive Go. When leaving the vehicle, the ID transmitter should also be taken and the vehicle locked from the outside.

## Emergency Start Coil

In unfavorable situations, the ID transmitter cannot be found in the passenger compartment. The Car Access System therefore causes a message to be output to the instrument cluster. The message tells the customer that the ID transmitter could not be found.

Because there is no slot for the ID transmitter in the F01/F02, there is an emergency start coil on the steering column. Communication via the emergency start coil allows the engine to be started and the vehicle is then ready to be driven.

The emergency start coil has the same function as the transponder coil. Communication via the transponder coil makes it possible for the Car Access System 4 to identify the ID transmitter. The Car Access System 4 can issue the start authorization following successful identification.

The remote control or ID transmitter cannot be found in the following situations:

- Fault in the remote control/ID transmitter
- Interference in the transmission to the remote control/ID transmitter
- Flat battery in the remote control/ID transmitter.



**Emergency start coil**


# System Components

## Control Unit

The Car Access System is located above the steering column on the right-hand side. For the Comfort Access function, the Car Access System controls the transmitting antennas for the vehicle exterior and interior.

The outside door handle electronics are read by the Car Access System.

### Installation location of the Car Access System 4 with Comfort Access



Index	Explanation	Index	Explanation
1	Car Access System 4 with Comfort Access	5	Central gateway module
2	Junction box electronics	6	Outside door handle electronics
3	Remote control receiver in the diversity module	7	Antennas for Comfort Access
4	Footwell module	8	Central locking components in the trunk

## Control Elements

### ID Transmitter

The ID transmitter for Comfort Access must be actuated by means of a radio signal. The ID transmitter is therefore equipped with a receiver for the coded 125 kHz radio signal that is transmitted by the Comfort Access antennas. The radio signal wakes the ID transmitter. The ID transmitter registers with the vehicle automatically (authentication).

For this purpose, the ID transmitter emits a coded 315 MHz high-frequency signal to enable identification of the ID transmitter as being valid and belonging to the vehicle.

The ID transmitter is exclusively responsible for use of the Comfort Access system. The ID transmitter has a battery, the service life of the battery in the ID transmitter is about 4 years.

### Voltage Monitoring

The ID transmitter monitors its own battery voltage. The battery voltage is monitored in 2 stages.

The first stage signals to the Car Access System 4 that the battery is flat. In response, the Car Access System 4 generates a check control message. The check control message informs the customer that the battery needs to be changed.

If the battery is not changed, the voltage monitoring facility switches to the second stage. This means that the data in the ID transmitter is saved. The ID transmitter is then set to “inoperative”.

### F01/F02 ID transmitter



Index	Explanation	Index	Explanation
1	Top view of ID transmitter	6	Rear view of ID transmitter
2	Vehicle unlock button	7	Transponder coil
3	Vehicle lock button	8	Battery compartment
4	Trunk unlock button	9	Mechanical key button
5	Follow-me-home lights button	10	Mechanical key

---

## Data for Conditioned Based Service

From terminal status “terminal 15 ON”, data for the Conditioned Based Service is transferred to the ID transmitter in the high-frequency range. The ID transmitter then confirms that the transmission was received.

## Antennas for Comfort Access

Eight antennas are installed for the Comfort Access system. Five antennas are for the vehicle interior and three are for the vehicle exterior.

The antennas for the exterior and interior are inductive antennas and have a ferrite core.

The antenna transmission frequency is 125 kHz . All messages that are sent via the antennas are encrypted.

## Antenna Installation Locations

### ■ Exterior antennas

The exterior antennas are installed in the following locations on the F01/F02:

- Door sill on the driver’s side, in the center of the vehicle
- Door sill on the front-passenger side, in the center of the vehicle
- Rear bumper in the center



### Passenger-compartment antenna in the door sills in the F01/F02

The antennas are designed to give about 5 feet (1.5 m) of coverage around the vehicle.

The exterior antennas are equipped with a splash-proof plug connection.

### ■ Interior antennas

The interior antennas are installed in the following locations in the F01/F02:

- Passenger compartment, front center console
- Passenger compartment, middle center console
- Luggage compartment, left and right
- Parcel shelf

---

The antenna characteristic is spherical. The entire vehicle interior is covered by the front and middle antennas.



### **Front passenger-compartment antenna in the F01/F02**

#### **■ Luggage compartment antenna**

The luggage-compartment antennas are of the same design as the interior antennas. They are integrated in the left- and right-hand sides of the luggage compartment.

The luggage-compartment antennas are configured so that they cover the entire luggage compartment.

---

## Outside Door Handle Electronics Module

The outside door handle electronics are connected to terminal 30F and work within a voltage range of 9 V to 16 V. The Car Access System is directly connected to the data line of the outside door handle electronics. This provides the Car Access System with information about the capacitive sensors and the piezo sensors. The status of the “pull” Hall sensor is monitored directly by the Car Access System.

The outside door handle electronics detect the status of the outside door handle using the sensors.

Each change in the status of the outside door handle module triggers the corresponding function.

These functions are:

- Trigger pulse by inserting a hand into the handle recess of the outside door handle; Capacitive sensor 1
- Unlock request by pulling the outside door handle; Hall sensor
- Lock request by pressing the sensitive area on the outside door handle; capacitive sensor 2 plus piezo sensor.

### Sensors

#### ■ Capacitive sensor 1

If a hand is placed into the handle recess of the outside door handle, for example, this is detected by the outside door handle electronics. On detecting this, the outside door handle electronics send the request to the Car Access System. The request initially contains the information to wake up the Car Access System. The Car Access System is woken and reads the request. Then, the Car Access System establishes communication with the ID transmitter.

The Car Access System switches the remote control receiver on permanently and therefore ensures that the data sent by the ID transmitter can be received.

**Note: The remote control receiver is integrated in the diversity module.**

#### ■ Capacitive sensor 2/piezo sensor

Touching the sensitive surface generates the capacitive sensor 2 signal. Together with the piezo sensor, a press on the sensitive surface is detected. A lock signal is only triggered if the capacitive sensor and piezo sensor are both actuated.

The outside door handle electronics analyze the two sensors and send the request to the Car Access System.

---

### ■ Outside door handle Hall sensor

The Hall sensor is redundant to the capacitive sensor 1. The Hall sensor is analyzed directly by the Car Access System. The Car Access System monitors the Hall sensor using a clocked voltage supply.

If the vehicle has already been woken by someone reaching into the handle recess, pulling on the outside door handle triggers the unlocking on the vehicle.

In unfavorable situations, it may be necessary to pull on the outside door handle twice to trigger the vehicle unlocking. This is caused if the signal from the capacitive sensor 1 is not present or is implausible.

### Door Locks

The vehicle has rapid opening locks in the doors as standard. A spring exerts pretension on the central locking drive for the unlocking procedure. The door is already unlocked before an attempt is made to open it with the outside door handle.

**Note: However, if the outside door handle is pulled very fast, the vehicle door may not yet be unlocked. In this case, it is necessary to pull the outside door handle a second time in order to open the door.**